


























ASSEMBLY INSTRUCTION

ITEM : TV-181


A	B	C	D	E	F	G	H
 x1	 x1	 x2	 x2	 x1	 x1	 x1	 x1
I	J	K	L	M	N	O	P
 x1	 x1	 x1	 x1	 x1	 x1	 x1	 x2
Q	R	S	T	U	V	W	X
 RED x2	 GREEN x2	 x1	 GR-22F x14	 GP-50 x8	 QK x8	 ESK-6 x4	 ETK-10 x4
							Y
							 FF x1

ADULT ASSEMBLE


ASSEMBLY INSTRUCTION

ITEM : TV-181


1




2




3



4




5



6



COMPLETE



ADULT ASSEMBLE